



POPCORN MACHINE

Plug in the machine. Oil, butter and popcorn are in the cabinet under the machine.

Turn on all red switches in front to make popcorn. To make popcorn add oil, kernels and butter (specific directions located next to machine) too heated pot. Close doors and wait for kernels to pop, you may need to dump pot as it gets towards the end of popping. **Once popped, you will need to turn off the rotator and pot heater switches. Only leave heat lamp on.**

To clean – turn off all switches, empty out unused popcorn and empty bottom tray. Wipe out machine and unplug. Be sure to store all supplies back in the cabinet.

